

Phone & Feature Guide




AT&T Avail™ 2

Phone Setup

You'll need to set up your AT&T Avail™ 2 before you can explore all its great features.

- Remove the back cover via the notch at the bottom of the phone.
- Insert the SIM card with the cut corner first and the gold-colored contacts facing down.
- Insert the microSD™ card (sold separately) with the gold-colored contacts facing down.
- Insert the battery, making sure the connectors align. Gently push down on the battery until it clicks into place.
- Replace the back cover.



Get to Know Your Phone




Note: For more information on your device, visit att.com/Tutorials.

Touch Screen and Navigation

Your phone features a capacitive touch screen, so you can gently tap, quickly swipe, or pinch with two fingers to navigate.

Navigating Your Phone

- Use your fingertip to lightly touch the screen.
- Use quick flicks of your finger on the touch screen to swipe up, down, left, and right.
- Spread two fingers apart or pinch them together on the screen to zoom in or out on a web page or a gallery image.
- The Notifications panel at the top of the screen provides quick access to alerts including new messages, email, and voicemail. Swipe down on the black bar to see more details. Flick up or press to close the panel.
- To return to the previous screen, press .
- Press at any time to return to the main home screen. Press and hold to access your recent apps.
- Press to access menu options for the screen you are on.
- Tap to access applications on your phone.



Customize a Home Screen

Change the wallpaper, add shortcuts to apps and widgets to the home screen, and create folders to organize and personalize your phone.

Set Wallpaper

- Press and hold a blank part of the home screen and touch **Home** or **Lock screen**.
- Tap **Gallery**, **Live Wallpapers** or **Wallpapers** and choose the image or animation you want to use as the wallpaper.
- Tap **Done** (for Gallery images) or **Set wallpaper**.



Add Shortcuts to Home Screen

- Tap and then choose **Apps** or **Widgets**.
- Press and hold the icon of the item you wish to add and then drag it to a home screen.
- To move an icon, press and hold it and drag it to a new location. To delete it, drag it to **Remove**.



Organizing Home Screens

- Press and hold an icon and drag it to **folder**.
- To add apps, drag additional icons to the folder.
- To rename a folder, tap it and then tap the name to bring up the keyboard. Enter a name and tap **Done**.

Find More Information

On the Web:

- Find tutorials at att.com/Tutorials.
- Find device specifications, user manuals, troubleshooting, and user forums at att.com/DeviceSupport.
- Manage your wireless account, including suspending service if your phone is stolen, at att.com/myatt.

On the Phone:

- Call AT&T Customer Care at **1-800-901-9878** or dial **611** from any AT&T mobile phone for assistance with your service or device.

Accessories

Accessories for your smartphone are available at att.com/WirelessAccessories or visit your local AT&T store.



Bluetooth Headset

Headset

Incipio Case



USB Cable



Vehicle Power Charger

Calling and Voicemail



Call friends and family and check voicemail in just a few simple steps.

Make a Call

- From the home screen, tap .
- Enter a phone number or spell the name of a contact. Tap the contact and then tap to place the call.

Check Voicemail

- From the home screen, tap .
- Press and hold the **1 Key**.
- Follow voice prompts to listen to messages.



GoPhone Account

Auto Refill


Take the hassle out of refilling your account by enrolling in Auto Refill.

From Your Device

- Call **611** from your phone.
- From the main menu, say "More options," and then say, "Set up auto pay."

Online

- Visit att.com/mygophone.
- Under **Auto Refill**, select **Sign Up > Manage My Account > Auto Refill**.



Add Money With a Credit Card, Debit Card, or Checking Account

- Call **611** from your phone and say "Add money."
- Go to www.att.com/mygophone and select the **Electronic payment** link.

Add Money by Purchasing a GoPhone Refill Card

Add money by purchasing a GoPhone Refill Card, which is available at authorized retail locations nationwide. With most refill cards, you can add the value directly from your phone.


- Dial **611** from your phone and say "Add money."
- Enter ***888***, followed by your PIN, the **# key**, and then press **Send**.
- Go to att.com/mygophone and select the **Use Refill Card** link.

Contacts

Keep the contact information of your favorite people in the address book. Importing and editing contacts is easy.


Import Contacts from SIM Card

- From the home screen, tap .
- Press and tap **Import/export > Import from SIM card**.
- Tap the contacts you wish to import, or tap **All** to select all contacts, and then tap **Import**.



Edit a Contact


- From the home screen, tap .
- Tap a contact name and tap **Edit**.
- Change details as needed and tap **Done**.






Email



Access your Gmail™, corporate email, and personal email wherever you are!

Email Setup

- 1 From the home screen, tap .
- 2 Enter your email address and password and then tap **Next**.
- 3 Confirm email account settings and tap **Next**.
- 4 Name the account, enter your name as it will appear on outgoing messages, and tap **Next**. Your email will begin to synchronize with your phone.

Create and Send an Email

- 1 From your email inbox, tap .
- 2 Enter an email address or tap  to access your contacts list.
- 3 Enter a subject and email message. To attach files to the email message, press , tap **Attach file**, and make your selection.
- 4 Tap **Send** to send your message.




Note: To set up corporate email, contact your IT administrator.






Internet



Browse the web and open multiple windows at the same time, as you would on your PC.

Opening a Web Page

- 1 From the home screen, tap .
- 2 Tap the address bar, enter a web address, and tap **Go**.





Browsing Options



- **Go back:** Tap .
- **Go forward:** Tap .
- **Refresh the page:** Tap .
- **Open another browser window:** Tap .
- **View open browser windows:** Tap .



Updating Your Apps

Updating apps is quick and easy.




- 1 From the home screen, tap .
- 2 Press  and tap **My apps**.
- 3 Tap . Or, if you'd like to update apps individually, tap the desired app > **Update** > **Accept & download**.
- 4 Once installed, you will see a notification in the Notifications panel. Open the app from this notification or by locating the app in the App tray .




Text and Picture Messaging


Send text or picture messages to communicate privately and quickly.


Send a Text Message

- 1 From the home screen, tap .
- 2 Tap  to start a new text message.
- 3 In the **To** field, enter a number or a contact name or tap  to access your contacts.
- 4 Tap the **Type message** field and enter your message.
- 5 Tap **Send** to send the message.



Send a Picture Message

- 1 Follow steps 1-4 above.
- 2 Tap .
- 3 Tap **Pictures** and select desired picture.
- 4 Tap **Send** to send the message.






Please don't text and drive.

Camera and Video Recording




Take pictures and record videos right from your phone with the camera and camcorder and then share them with friends and family.

Take a Picture

- 1 From the home screen, tap .
- 2 Tap  to adjust your camera settings. Zoom in and out by dragging the slider bar.
- 3 Tap  or press a Volume key to take a photo.





Record a Video

- 1 In camera mode, tap  to switch to the camcorder.
- 2 Tap  to start recording video and tap  to stop.




Share a Picture


- 1 From the home screen, tap .
- 2 Tap an album and then tap a photo.
- 3 Tap  and select an option for sharing.

Bluetooth® and Wi-Fi®


Pair with other *Bluetooth* devices or connect to a Wi-Fi network.


Connect to a Bluetooth Headset

- 1 From the home screen, press  and tap **System settings** > **Bluetooth**.
- 2 Tap **OFF** to turn *Bluetooth* on.
- 3 Your phone will automatically search for devices. Tap the name of a device to pair and connect with it.



Connect to a Wi-Fi Network


- 1 From the home screen, press  and tap **System settings** > **Wi-Fi**.
- 2 If Wi-Fi is off, tap **OFF** to enable it.
- 3 Tap a network name. Enter a password if required and then tap **Connect**.




Google Play™ Store



Browse and download apps, games, books, movies, and more with Google Play.


Access Google Play

- 1 From the home screen, tap .
- 2 Sign in with your existing Google™ account or create one following the steps on the screen.








Navigate Google Play


- 1 Tap a category to browse popular apps, games, movies, and music organized by popularity or category.
- 2 Tap  to search the Play Store for a specific game or app.
- 3 To install, tap the app and follow instructions. Once installed, you will see a notification in the Notifications panel. Open the app from this notification or by locating the app in the App tray .



Multitasking







You can perform multiple tasks at once with Avail 2, such as looking at an email while on a phone call.

- 1 While on a call, press :
 - To begin a new text message or email, tap  or .
 - To access additional applications, tap .
- 2 To return to the call screen, tap .



AT&T Services

Check out these handy apps from AT&T.


-  **AT&T Drive Mode™:** Silence notifications, set an auto-reply so people will know you're driving, and more.
-  **AT&T Locker™:** Safely store and share all your photos, videos, and documents with up to 5 GB of free storage.
-  **AT&T Navigator®:** Get voice-guided, turn-by-turn driving directions and traffic updates.
-  **AT&T Smart Wi-Fi:** Maximize your battery performance and data plan, simplify access to AT&T Hot Spots and Wi-Fi networks, automate your Wi-Fi connections, and track your data usage.
-  **Data Balance:** Track your remaining data and messaging balance.
-  **Mobile TV:** Watch LIVE, on-demand, and downloadable mobile TV.


Data rates may apply. Mobile TV and AT&T Navigator require a separate subscription. Mobile TV requires mobile broadband service. Service not available in all areas. Programming subject to blackout restrictions. Download and watch capability available for select content, requires Wi-Fi connection, and is available for viewing for limited time periods.

AT&T DriveMode

When your vehicle is in motion, automatically respond to incoming texts and emails. Texting while driving—it can wait.


Getting Started

- 1 From the home screen, tap .
- 2 Read and accept the Terms and Conditions.
- 3 Read the welcome screen.
- 4 Tap **Continue** to set up.



Set Up App Features

- Create auto-reply message*
- Choose auto-reply message distribution.
- Set up "allow list"—up to five numbers.
- Confirm Auto-ON or Auto-OFF mode.



Note: A Google Wallet™ payment method is required to purchase apps.

*Standard messaging rates apply to auto-reply messages. AT&T DriveMode is free to AT&T customers only.