

Phone & Feature Guide



AT&T Z432

Getting to Know Your Phone





Tips	
4-Way Navigation Key	From the home screen: Up: SMS Left: My Stuff Down: Address Book Right: Alarm
Send Key	From the home screen: Press to view call history.
Space Key	From the home screen: Press and hold to activate silent mode with vibration.

Note: For more information on your device, visit att.com/tutorials.

Mobile Web

Access the Internet on the go! Check weather, news, and visit your favorite sites right on your mobile phone.

- From the home screen, press the **Right Soft Key for Main Menu** and select **Browser (5)**.
- Press the **Left Soft Key for Options** and select **New Link [*] (1)** to enter a website address.
- Type a website address directly into the URL field, or scroll down the list of recent websites using the **4-Way Navigation Key**.
- Press the **OK Key**.
- While browsing, you can access a list of favorite sites by choosing **Options > Go to (3) > Bookmarks (1)**.
- To add a site to the list, select **Options > Web Page Options (4) > Add to Bookmarks (3) > Save**.



Setting Up Your Phone

Customize and personalize your phone with sound profiles, wallpaper, ringtones, and more.

Settings

① From the home screen, press the **Right Soft Key for Main Menu**.

② Select **Settings (#)**.

- Display Settings** – adjust theme, wallpaper, backlight, and more.
- Phone Settings** – assign shortcut keys, change the language, set the date and time, view phone info, enable TTY, and more.
- Profiles** – adjust alert tones, ringtones, and ring volume and type for each sound profile.
- Call Settings** – enable call forwarding, activate call waiting, change answer mode, and more.
- Connection Settings** – connect to *Bluetooth*® devices and edit modem and access point settings.
- Security Settings** – reset your device, turn on or change PIN and phone lock codes, and edit fixed dial numbers.
- AT&T Software Update** – check for software updates to your device.



Note: In any of the above menus, highlight an option and press the **OK Key** to select and adjust your settings.

Find More Information

On The Web:

- Find tutorials at att.com/Tutorials.
- Find device specifications, user manuals, troubleshooting, and user forums at att.com/DeviceSupport.
- Manage your wireless account, including suspending service if your phone is stolen, at att.com/myatt.

On The Phone:

- Call AT&T Customer Care at **1-800-331-0500** or dial **611** from any AT&T mobile phone for assistance with your service or device.

Camera

Capture those special moments right on your phone and then send them to friends and family!

Take a Picture

- From the home screen, press and hold the **Camera Key** to access the camera.
- Press the **Left Soft Key** to access camera settings such as brightness, contrast, white balance, effect, quality, and more.
- Press the **OK Key** or the **Camera Key** to take a photo.
- Your picture will be saved to the My Pictures folder.



Send a Picture



- After taking a picture, press the **OK Key** for options.
- Choose **Send > As Multimedia Message**.
- Highlight the **To field**, and enter a contact name or phone number(s). You can also press the **OK Key** to add recipients from the Address Book.
- Scroll down to the **Text field** and type your message.
- Press the **OK Key** to send your picture message.

Text and Picture Messaging

Use text messaging to quickly and privately send text messages to other wireless phones and email addresses.

Send a Message

- 1 From the home screen, press the **Right Soft Key** for **Main Menu**.
- 2 Select **Messaging (3)** > **Create New Message**.
- 3 Enter a contact name or phone number(s). You can also press the **OK Key** to add recipients from the Address Book.
- 4 Scroll down to the **Text field** and type your message.
- 5 Press the **OK Key** to send the message.



Add a Picture



- 1 When you create a message, scroll down and select **Add Picture**.
- 2 You can take a new picture or choose one from your gallery.
- 3 Press the **OK Key** to send the message.

Please don't text and drive.

Multitasking

Browse the web, send and receive messages, and listen to music, all at once! One key changes your task quickly and easily.



- 1 If you're involved in one task and want to switch to or launch another, press **□**. You can then select the home screen, Main Menu, or another open task.
- 2 To end a task, scroll to the task and press the **Left Soft Key**.



Bluetooth

Take advantage of *Bluetooth* wireless technology to connect to headsets, speakerphones, computers, and more!

- 1 Before you begin, place your *Bluetooth* device into pairing mode. From the home screen, press the **Right Soft Key** for **Main Menu**.
- 2 Select **Settings (#)** > **Connection Settings** > **Bluetooth**.
- 3 Press the **OK Key** to set *Bluetooth* to **On**.
- 4 Select **Search for Devices** to search for devices near you.
- 5 Highlight the name of the device that you would like to pair with and press the **OK Key**. You may need to confirm a passkey.*




*Please consult the documentation included with the *Bluetooth* device for information on placing the device into pairing mode and entering the passkey (typically 0 0 0 0 – four zeroes).

AT&T Navigator®

Get traffic updates, GPS navigation, and turn-by-turn driving directions on your mobile phone with AT&T Navigator.

- 1 From the home screen, press the **Right Soft Key** for **Main Menu** and select **AT&T Navigator (1)**.
- 2 Press the **Left Soft Key** to accept the Terms of Service.
- 3 If this is the first time you have accessed AT&T Navigator, you will be prompted to take a feature tour.
- 4 To start a trip, select **Drive To > Address (3)**. Select **Type It** to enter an address using the keyboard, or choose **Speak It**. Press the **OK Key** for **Done**.
- 5 To stop navigation, press the **Right Soft Key** for **Home** and press the **OK Key**.
- 6 To access Navigator Settings, access the Navigator home screen and choose **Share & More > Preferences (7)**.
- 7 Highlight an option and press the **OK Key**.




Additional charges may apply.

Mobile Email

Carry your inbox in your pocket! Access AOL®, Yahoo!® Mail, Gmail™, AIM®, and Hotmail® with Mobile Email.

Set Up an Email Account

- 1 From the home screen, press the **Right Soft Key** for **Main Menu** and select **Email (4)**.
- 2 Choose a provider from the list. You can add up to five accounts.
- 3 When you select **Other Providers**, you may be asked to accept terms of service and/or select your email domain. Follow the on-screen instructions.
- 4 Scroll down and press the **OK Key** to sign in.



Send an Email

- 1 From the home screen, press the **Right Soft Key** for **Main Menu** and select **Email (4)**.
- 2 Highlight the account you wish to use and press the **OK Key**.
- 3 Press the **Left Soft Key** for **Options > Compose New (5)**.
- 4 Enter a contact and your message.
- 5 Press the **Left Soft Key** for **Options > Send (5)** to send the email.


Additional charges may apply.

Change Your Ringtone

You can change your ringtone in Music or Settings.


Through Music

- 1 From the home screen, press the **Right Soft Key** for **Main Menu** and select **Music (6)**.
- 2 Select **Ringtones**.
- 3 Press the **OK Key** to preview a ringtone.
- 4 Highlight a file and choose **Options**.
- 5 Select **Set as (1) > Voice Call Ringtone (1)**.



Through Settings

- 1 From the home screen, press the **Right Soft Key** for **Main Menu**.
- 2 Select **Settings (#)** > **Profiles**.
- 3 Highlight the **General** or **Outdoor** profile and choose **Edit**.
- 4 Choose **Voice Call Ringtone**.
- 5 Highlight a ringtone and press the **OK Key** to select it.



Additional charges may apply.