

Phone & Feature Guide



Need more help? Go to [APPS > Device Help](#).

ZTE MAVEN™



Install SIM/microSDHC™ Cards

You'll need to set up your ZTE Maven™ before you can explore all its great features.

① Remove the back cover via the notch at the bottom of the phone.

② Your new GoPhone SIM card is pre-installed. If you are an existing AT&T customer, replace it with your current SIM (see instruction #3 below). If your SIM does not fit, use the new SIM that is already inserted and call Customer Care at 800-331-0500 to update your account.

③ To insert a SIM card, push the SIM into the card slot with the gold color contacts facing down.

④ Insert the microSDHC (sold separately) with the gold-colored contacts facing down.

⑤ Replace the back cover.



Touch Screen and Navigation

Your phone features a capacitive touch screen, so you can gently tap, quickly swipe, or pinch with two fingers to navigate.

Navigating Your Phone

- Use your fingertip to lightly tap the screen.
- Use quick flicks of your finger on the touch screen to swipe up, down, left, and right.
- Spread two fingers apart or pinch them together on the screen to zoom in or out on a web page or a gallery image.
- The Notifications bar at the top of the screen provides quick access to alerts including new messages, email, and voicemail. Swipe down on the black bar to see more details. Flick up or press to close the panel.
- To return to the previous screen, press .
- Press to return to the main home screen. Press and hold to access Google Now™.
- Press to view recently used applications.
- Tap to access applications on your phone.



Customize a Home Screen

Change the wallpaper, add shortcuts to apps and widgets on the home screen, and create folders to organize and personalize your phone.

Set the Wallpaper

- ① Press and hold a blank part of the home screen and tap **Wallpapers**.
- ② Tap **GALLERY** or **LIVE WALLPAPER** to choose the image or animation you want to use as the wallpaper. You can also tap a default image as the wallpaper.

Add Shortcuts to the Home Screen

- ① From the home screen, tap . You can also press and hold a blank part of the home screen and then choose **Widgets**.
- ② Press and hold the icon of the item you wish to add and then drag it to a home screen.
- ③ To move an icon, press and hold it and drag it to a new location. To delete it, drag it to **Delete**.

Organize Your Home Screens

- ① On a home screen, press and hold an app icon and drag it to **Folder**.
- ② You can add more apps to the folder by dragging icons to the folder.
- ③ Tap the folder to open it and access items in the folder.
- ④ To name the folder, open it and tap **folder**.
- ⑤ Enter a name and tap .

P/N : 079584507134

GoPhone Account

Auto Refill

Take the hassle out of refilling your account by enrolling in Auto Refill.

From Your Device

- ① Call **611** from your phone.
- ② From the main menu, say “More options,” and then say, “Set up auto pay.”

Online

- ① Visit att.com/mygophone.
- ② Under Auto Refill, select **Sign Up > Manage My Account > Auto Refill**.

Add Money with a Credit Card, Debit Card, or Checking Account

- ① Call **611** from your phone and say, “Add money.”
- ② Go to att.com/mygophone and select the **Credit Card Payment** link.

Add Money by Purchasing a GoPhone Refill Card

Add money by purchasing a GoPhone Refill Card, which is available at authorized retail locations nationwide. With most refill cards, you can add the value directly from your phone.

- ① Dial **611** from your phone and say “Add money.”
- ② Enter ***888***, followed by your PIN, the **# key**, and then press **Send**.
- ③ Go to att.com/mygophone and select the **Refill** link.

Contacts and Phone Calls

Keep the contact information of your favorite people in the address book. Call friends and family and check voicemail in just a few simple steps.

Import Contacts from the micro-SIM Card

- ① From the home screen, tap .
- ② Tap > **Import/Export > Manage SIM card contacts**.
- ③ Select an account in which to save the contacts.
- ④ Tap > **Import SIM Contacts**.
- ⑤ Tap to select the contacts you need and then tap .

Edit a Contact

- ① From the home screen, tap .
- ② Tap a contact name and tap .
- ③ Change details as needed and tap .

Make a Call

- ① From the home screen, tap .
- ② Spell the name or phone number of a contact in the search box at the top of the screen, or tap and enter a phone number. Tap the contact or tap to place the call.

Check Voicemail

- ① From the home screen, tap > .
- ② Press and hold the **1 Key**.
- ③ Follow voice prompts to listen to messages.

Email


Access your Gmail™, corporate email, and personal email wherever you are!

Email Setup

- ① From the home screen, tap .
- ② Tap the email server you wish to use.
- ③ Enter your email address and password and then tap **Next**.
- ④ Confirm email account settings and tap **Next**.
- ⑤ Name the account, enter your name as it will appear on outgoing messages, and tap **Next**. Your email will begin to synchronize with your phone.

Create and Send an Email

- ① From your email inbox, tap .
- ② Enter an email address or tap to access your contacts list.
- ③ Enter a subject and email message. To attach files to the email message, tap > **Attach file**, and make your selection.
- ④ Tap **Send** to send your message.



Text and Picture Messaging


Send text or picture messages to communicate privately and quickly.

Send a Text Message

- ① From the home screen, tap .
- ② Tap to start a new text message.
- ③ In the **To** field, enter a number or a contact name, or tap to access your contacts.
- ④ Tap the **Type message** field and enter your message.
- ⑤ Tap to send the message.

Send a Picture Message

- ① Follow steps 1-4 above.
- ② Tap .
- ③ Tap **Pictures** and select desired picture.
- ④ Tap to send the message.







Note: To set up corporate email, contact your IT administrator.

Please don't text and drive.

Update Your Apps

Updating apps is quick and easy.




- ① From the home screen, tap .
- ② Tap  > **My apps**.
- ③ Tap **UPDATE ALL**. Or, if you'd like to update apps individually, tap the desired app **UPDATE** > **ACCEPT**.
- ④ Once installed, you will see a notification in the Notifications bar. To open the app, locate it in the App tray.






Camera and Video Recording

Take pictures and record videos right from your phone with the camera and camcorder and then share them with friends and family.



Take a Picture

- ① From the home screen, tap .
- ② Tap  to adjust your camera settings. Zoom in and out by pressing the volume key.
- ③ Tap  to take a photo.

Record a Video

- ① In camera mode, tap  to adjust your camcorder settings.
- ② Tap  to start and tap  to stop recording video.





Share a Picture or Video

- ① From the home screen, tap  > **Gallery**.
- ② Tap an album and then tap a photo or video. Tap  > **Share** and select an option for sharing.



Network Indicators







Your 4G LTE wireless device will indicate which of the AT&T wireless networks you are connected to. A network indicator does not necessarily mean that you will experience any particular upload or download data speeds.

-  **4G LTE:** Connected to the AT&T 4G LTE network.
-  **4G:** Connected to the AT&T HSPA+ network. The AT&T HSPA+ network is capable of delivering 4G speeds when combined with enhanced backhaul. 4G availability is increasing with ongoing backhaul deployment.
-  **3G:** Connected to AT&T's 3G network.
-  **Edge:** Connected to the AT&T EDGE/2G network.

Actual data upload and download speeds depend on various factors, including the device, network utilization, file characteristics, terrain, etc. Learn more at: wireless.att.com/learn/articles-resources/wireless-terms.jsp, your AT&T Wireless Customer Agreement, Section 3.2 “Where and How Does AT&T Service Work?”
4G LTE not available everywhere. LTE is a trademark of ETSI. Learn more at att.com/network.

AT&T Services

Check out these handy apps from AT&T.



-  **DriveMode®:** Silence notifications, set an auto-reply so people will know you're driving, and more.
-  **AT&T Locker™:** Safely store and share all your photos, videos, and documents with up to 5 GB of free storage.
-  **AT&T Navigator®:** Get voice-guided, turn-by-turn driving directions and traffic updates.
-  **AT&T Mail:** Access your AT&T Mail wherever you are.
-  **AT&T Live:** Brings you a virtually endless stream of personalized news.
-  **Mobile TV:** Watch live, on-demand, and downloadable mobile TV.


Data rates may apply. Mobile TV and AT&T Navigator require a separate subscription. Mobile TV requires mobile broadband service. Service not available in all areas. Programming subject to blackout restrictions. Download and watch capability available for select content, requires Wi-Fi connection, and is available for viewing for limited time periods.

Bluetooth® and Wi-Fi®



Pair with other *Bluetooth* devices or connect to a Wi-Fi network.


Connect to a Bluetooth Headset

- ① From the home screen, tap  > **Settings** > **Bluetooth**.
- ② Tap  to turn *Bluetooth* on.
- ③ Your phone will automatically search for devices. Tap the name of the device to pair and connect with it.




Connect to Wi-Fi Network

- ① From the home screen, tap  > **Settings** > **Wi-Fi**.
- ② If Wi-Fi is off, tap  to enable it.
- ③ Tap a network name. Enter a password if required and then tap **CONNECT**.



Optimize Battery Life

There are several things you can do to make your battery last longer.

- Turn on Wi-Fi, *Bluetooth*, GPS, mobile data, and auto-sync only when you need to.
- Lower the screen brightness.
- Use *Bluetooth* tethering or USB tethering (when you have a cable) instead of portable Mobile Hotspot to share your phone's data service.
- From the home screen, tap  > **Task Manager** and close the apps you do not need but still run in the background.

Accessories

Accessories for your smartphone are available at att.com/WirelessAccessories or visit your local AT&T store.



Bluetooth Headset



Headset



USB Cable




Vehicle Power Charger

Find More Information

On the Web

- Find tutorials at att.com/Tutorials.
- Find device specifications, user manuals, troubleshooting, and user forums at att.com/DeviceSupport.
- Manage your wireless account, including suspending service if your phone is stolen, at att.com/myatt.

On the Phone

- To access how-to videos for the ZTE Maven, tap  > **Device Help**.
- Call AT&T Customer Care at **1-800-331-0500** or dial **611** from any AT&T mobile phone for assistance with your service or device.

ZTE, Maven, and the ZTE logos are trademarks of the ZTE Corporation. © 2015 AT&T Intellectual Property. All rights reserved. AT&T, the AT&T logo and all other AT&T marks contained herein are trademarks of AT&T Intellectual Property. All other marks contained herein are the property of their respective owners.