

# DISCOVER THE ADVENTURE

## PHONE & FEATURE GUIDE

Z8090183400MT

Tomorrow never waits

## Setting Up Your Phone

### Installing a microSDHC™ Card

The microSDHC card can be installed and removed while the phone is turned on. Unmount the microSDHC card before removing it.

- Place your finger in the slot at the bottom of the back cover to lift and remove the cover.
- Hold your microSDHC card with the metal contacts facing down and slide it into the microSDHC card slot.
- Press the cover gently back into place until you hear a click.

### Charging the Battery

When you first get your new phone you'll need to charge the battery. If the battery is low, there will be a pop-up message on the screen. As you charge your phone, the screen will tell you the exact battery level each time you wake up your phone.

**WARNING!** Use only ZTE-approved chargers and cables. The use of unapproved accessories could damage your phone or cause the battery to explode.

- Connect the adapter to the charging port. Ensure that the adapter is inserted with the correct orientation. Do not force the connector into the charging port.
- Connect the charger to a standard AC wall outlet. If the phone is on, you'll see a charging icon, such as or appear in the Status Bar.
- Disconnect the charger when the battery is fully charged.

## Getting to Know Your Phone



\*Customizable. See Touch Screen and Navigation Keys panel.

## Notifications

The status bar at the top of the home screen provides phone and service status icons, and notification icons.

### Phone and Service Status Icons

	GPRS connected		Battery low
	EDGE connected		Battery full
	3G connected		Battery charging
	4G connected		Vibration mode
	Airplane mode		Bluetooth on
	No signal		Bluetooth connected
	Signal strength		Connected to a Wi-Fi network
	Mobile data in use		Wi-Fi in use
	No SIM card installed		GPS on
	Alarm set		

### Notification Icons

	New SMS		Song is playing
	New MMS		Wired headset connected
	New email		microSDHC card unmounted
	New Gmail message		microSDHC card removed
	Missed call		Upcoming event
	Call in progress		Incoming file via Bluetooth
	Call on hold		New Wi-Fi network detected
	USB connected		Downloading data
			Sending data

## Touch Screen and Navigation Keys

- Power/Lock Key:** Press and hold to power on, restart the phone, turn on/off airplane mode, or power off. Press to turn on/off the screen display.
- Home Key:** Press to return to the home screen from any application or screen. Press and hold to access Google Now™.
- Recent Apps Key:** Press to view recently used apps.
- Back Key:** Press to go to the previous screen.
- Volume Key:** Press to turn the volume up or down or to enable silent mode/vibration mode.

### Opening Applications

- Press if the current screen is not the home screen.
- Tap .
- Swipe left or right on the screen and tap an app to open it.

### Personalize

You can exchange the positions of the Back Key and Recent Apps Key. Press > > **Settings** > **Navigation key** and select an option.

## Internet

### Connecting via Wi-Fi\*

- From the home screen, tap > **Wi-Fi**.
- Slide the on/off switch if Wi-Fi is off. Your phone automatically searches for Wi-Fi networks in range and displays their names and security settings. Your phone also connects to previously linked networks when they are in range.
- Tap a network name to connect to it.
- If the network is secured, enter a password or other credentials (ask your network administrator for details) and tap **CONNECT**.

### Connecting via Mobile Network

- From the home screen, tap > **Mobile networks** > **Mobile Data**.
- Slide next to **Standard Data** to enable mobile data.

## Calling and Voicemail

### Making a Call

- From the home screen, tap > .
- Enter the phone number with the on-screen keypad. Tap to delete incorrect digits.
- Tap to place the call. **NOTE:** To call a contact, press > > **CONTACTS** and tap .

### Checking Voicemail

- From the home screen, tap > .
- Tap and hold the **1 Key**. If prompted, enter your voicemail password.
- Follow the voice prompts to listen to and manage your voicemail messages.

**NOTE:** To set your voicemail service, tap > > **Call Setting** > **Voicemail** and tap the voicemail settings you want to change. For detailed information, please contact the service provider.

## Address Book

### Creating a New Contact

- From the home screen, tap .
- Tap .
- Enter the contact name, phone numbers, email addresses, and other information, as shown.
- Tap to save the contact.

### Importing Contacts in Batches

- From the home screen, tap .
- Tap > **Import from storage**.
- Select an account in which to save the contacts.
- If prompted, choose to import one, multiple, or all vCard files.
- If prompted, tap **OK**.

## Text Messaging

- From the home screen, tap > .
- Enter the recipient(s) and message text. If you want to send an MMS, tap to add attachments.
- Tap to send the message.

*Please don't text and drive.*

## Email

### Setting Up Gmail™

- From the home screen, tap > **M**. **NOTE:** If another Gmail account is already set up, press > > **Accounts** > **Google**.
- Enter your existing Google email or tap **Or create a new account**.
- Follow the instructions on the screen to set up the account.

### Setting Up Email

- From the home screen, tap > and select an email server. **NOTE:** If another email account is already set up, press > > **Accounts** > **Email**.
- Enter the email address and password.
- Tap **Next** and follow the on-screen instructions.

## Customizing Home Screens

You can customize your home screen by adding applications, folders, widgets, and more.

### Adding Widgets

- Tap and hold an empty spot on a home screen.
- Tap **Widgets**.
- Tap and hold a widget and drag it to the desired home screen.

**NOTE:** To add an app to a home screen, tap and hold the app from the App Tray and drag it to a home screen.

### Removing Widgets or Apps

- Tap and hold a widget or app on the home screen.
- Drag it to to remove it.

### Organizing Apps With Folders

- Tap and hold an app icon.
- Drag it on top of another app icon and release. A new folder is created.
- If needed, drag more apps and drop them into the folder.

### Applying New Wallpapers

- Tap and hold an empty spot on a home screen.
- Tap **Wallpapers**.
- Select a wallpaper source (**GALLERY** or **LIVE WALLPAPER**) and choose an image or tap a wallpaper thumbnail image.
- Follow the instructions on the screen.

## Camera and Video

### Taking a Photo

- From the home screen, tap > .
- Aim the camera at the subject and make any necessary adjustments.
- Tap .

### Recording a Video


- From the home screen, tap > .
- Aim the camera at the subject and make any necessary adjustments.
- Tap to start and to stop recording.

**TIP:** While the recording is in progress, you can tap to save the frame as a photo.



## Playing Music

- From the home screen, tap > .
- Tap **All Songs**.
- Tap a song to play it.



## Connectivity

### Connecting With a Bluetooth® Headset

Turn on the Bluetooth headset and switch it to pairing mode. Refer to the headset's user guide for more information.

- From the home screen, tap > **Bluetooth**.
- Slide the on/off switch if Bluetooth is off. When Bluetooth is on, the icon appears in the status bar. **NOTE:** Your phone automatically scans for and displays the IDs of all available Bluetooth devices in range. You could tap > **Refresh** if you wanted to scan again.
- Tap the ID of the headset, or any other device you want to pair with your phone. Enter a passcode if prompted.
- If necessary, tap the ID of the paired headset to connect with it.

**TIP:** Tap the headset ID and then tap **OK** to end the connection.

## Google Play™

Google Play has tens of thousands of games and applications for you to enjoy. Before you begin, make sure that you are signed in to your Google account.

- From the home screen, tap .
- Find the apps you need either by category or by typing in the search field.
- Tap the app to see a more detailed description.
- Tap **INSTALL** (free apps) or the price (paid apps). **NOTE:** A payment method (such as Google Wallet™) is required to purchase apps.
- Read the app permissions and tap **ACCEPT**. **CAUTION:** Once installed, some apps can access many functions of a significant amount of your personal data. The Play Store will show you what the app can access.
- For paid apps, tap **CONTINUE** and follow additional on-screen instructions for payment.
- Wait for the app to be downloaded and installed automatically. Payment needs to be authorized before paid apps start downloading.
- The app is successfully installed when the icon appears in the status bar. You can find the new app after pressing > .

**NOTE:** The content you can access in the Play Store depends on your region and your service provider.

## For Your Safety

### FCC RF Exposure Information (SAR)

This phone is designed and manufactured not to exceed the emission limits for exposure to radio frequency (RF) energy set by the Federal Communications Commission of the United States. During SAR testing, this device was set to transmit at its highest certified power level in all tested frequency bands, and placed in positions that simulate RF exposure in usage against the head with no separation, and near the body with the separation of 10 mm. Although the SAR is determined at the highest certified power level, the actual SAR level of the device while operating can be well below the maximum value. This is because the phone is designed to operate at multiple power levels so as to use only the power required to reach the network. In general, the closer you are to a wireless base station antenna, the lower the power output. The exposure standard for wireless devices employs a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit set by the FCC is 1.6 W/kg. Tests for SAR are conducted using standard operating positions accepted by the FCC with the device transmitting at its highest certified power level in all tested frequency bands. The FCC has granted an Equipment Authorization for this model phone with all reported SAR levels evaluated as in compliance with the FCC RF exposure guidelines. SAR information on this model phone is on file with the FCC and can be found under the Display Grant section of [www.fcc.gov/oet/ea/fccid](http://www.fcc.gov/oet/ea/fccid) after searching on FCC ID: **SRO-Z716BL**. For this device, the highest reported SAR value for usage against the head is **0.78 W/kg**, for usage near the body is **1.18 W/kg**. While there may be differences between the SAR levels of various phones and at various positions, they all meet the government requirements. SAR compliance for body-worn operation is based on a separation distance of 15 mm between the unit and the human body. Carry this device at least 15 mm away from your body to ensure RF exposure level compliant or lower to the reported level. To support body-worn operation, choose the belt clips or holsters, which do not contain metallic components, to maintain a separation of 15 mm between this device and your body. RF exposure compliance with any body-worn accessory, which contains metal, was not tested and certified, and use such body-worn accessory should be avoided. Operations in the band 5.115-5.25GHz are restricted to indoor use only.

**FCC Compliance**  
This mobile phone complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

## For Your Safety (continued)

- Reorient or relocate the receiving antenna.
  - Increase the separation between the equipment and receiver.
  - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
  - Consult the dealer or an experienced radio/TV technician for help.
- CAUTION:** Changes or modifications not expressly approved by the manufacturer could void the user's authority to operate the equipment. The antenna(s) used for this transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

### Hearing Aid Compatibility (HAC) Regulations for Mobile Phones

In 2003, the FCC adopted rules to make digital wireless telephones compatible with hearing aids and cochlear implants. Although analog wireless phones do not usually cause interference with hearing aids or cochlear implants, digital wireless phones sometimes do because of electromagnetic energy emitted by the phone's antenna, backlight, or other FCC-regulated components. Your phone is compliant with FCC HAC regulations (ANSI C63.19-2011). While some wireless phones are used near some hearing devices (hearing aids and cochlear implants), users may detect a buzzing, humming, or whining noise. Some hearing devices are more immune than others to this interference noise, and phones also vary in the amount of interference they generate. The wireless telephone industry has developed ratings for some of their mobile phones to assist hearing device users in finding phones that may be compatible with their hearing devices. Not all phones have been rated. Phones that have been rated have a label on the box. These ratings are not guaranteed. Results will vary, depending on the level of immunity of your hearing device and the degree of your hearing loss. If your hearing device happens to be vulnerable to interference, you may not be able to use a rated phone successfully. Trying out the phone with your hearing device is the best way to evaluate it for your personal needs. This phone has been tested and rated for use with hearing aids for some of the wireless technologies that it uses. However, there may be some newer wireless technologies used in this phone that have not been tested yet for use with hearing aids. It is important to try the different features of this phone thoroughly and in different locations, using your hearing aid or cochlear implant, to determine if you hear any interfering noise. Consult your service provider or the manufacturer of this phone for more information regarding hearing device compatibility. Questions about return or exchange policies, consult your service provider or phone retailer.

**M-Ratings:** Phones rated M3 or M4 meet FCC requirements and are likely to generate less interference with hearing devices than phones rated M1 or M2. M4 is the better/higher of the two ratings.  
**T-Ratings:** Phones rated T3 or T4 meet FCC requirements and are likely to be more usable with a hearing device's telecoil ("T-Switch" or "Telephone Switch") than unrated phones. T4 is the better/higher of the two ratings. (Note that not all hearing devices contain telecoils.)

Your Z716BL has been tested for hearing aid device compatibility and has an **M3/T3** rating. Hearing devices may also be measured for immunity to this type of interference. Your hearing device manufacturer or hearing health professional may help you find results for your hearing device. For additional information about the FCC's actions with regard to hearing aid compatible wireless devices and other steps the FCC has taken to ensure that individuals with disabilities have access to telecommunications services, please go to [www.fcc.gov/gfb/dia](http://www.fcc.gov/gfb/dia).

### Distraction

Full attention must be given to operating machinery in order to reduce the risk of an accident. Using a phone while driving (even with a hands free kit) can cause distraction and lead to an accident. You must comply with local laws and regulations restricting the use of wireless devices while driving.

### Product Handling

**General Statement on Handling and Use**  
You alone are responsible for how you use your phone and any consequences of its use. You must always turn off your phone wherever the use of a phone is prohibited. Use of your phone is subject to safety measures designed to protect users and their environment.  
**Always** treat your phone and its accessories with care and keep it in a clean and dust-free place.  
**Keep** the screen and camera lens clean. Unclean screen or camera lens may slow down the phone's reaction to your operations or lower image quality.  
**Clean** the device and its accessories with a soft material such as cleaning cloth for eyeglass lenses. Do not use alcohol or other corrosive substances for cleaning or allow them to get inside.  
**Do not** expose your phone or its accessories to open flames or tobacco products.  
**Do not** expose your phone or its accessories to liquid, moisture or high humidity.  
**Do not** drop, throw or try to bend your phone or its accessories.  
**Do not** paint your phone or its accessories.  
**Do not** attempt to disassemble your phone or its accessories. Only authorized personnel can do so.  
**Do not** expose your phone or its accessories in an environment with or that can reach extreme temperatures, minimum -51 and maximum +150 degrees Celsius.  
**Do not** place your phone inside or near heating equipment or high-pressure containers, such as water heaters, microwave ovens, or hot cooking utensils. Otherwise, your phone may be damaged.  
**Please** check local regulations for disposal of electronic products.  
**Do not** carry your phone in your back pocket as it could break when you sit down.  
**Small Children**  
**Do not** leave your phone and its accessories within the reach of small children or allow them to play with it. They could hurt themselves or others, or could accidentally damage the phone. Your phone contains small parts with sharp edges that may cause an injury, or may be removed and create a choking hazard.

**Demagnetization**  
To avoid the risk of demagnetization, do not allow electronic devices or magnetic media to be close to your phone for a long time.  
**Electrostatic Discharge (ESD)**  
Do not touch the SIM/SD cards metal connectors.

**Antenna**  
Do not touch the antenna unnecessarily.  
**Normal Use Position**  
When placing or receiving a phone call, hold your phone to your ear, with the bottom towards your mouth.

**Air Bags**  
Do not place a phone in the area over an air bag or in the air bag deployment area as an airbag inflates with great force and serious injury could result. Store the phone safely before driving your vehicle.  
**Seizures/Blackouts**  
The phone can produce a bright or flashing light. A small percentage of people may be susceptible to blackouts or seizures (even if they have never had one before) when exposed to bright lights or light patterns such as when playing games or watching video. If you have experienced seizures or blackouts or have a family history of such occurrences, please consult a physician.

**Repetitive Stress Injuries**  
To minimize the risk of Repetitive Strain Injury (RSI) when texting or playing games with your phone:  
**Do not** grip the phone too tightly.  
**Press** the buttons lightly.  
**Use** the special features that are designed to minimize the times of pressing buttons, such as Message Templates and Predictive Text.  
**Take** many breaks to stretch and relax.

**Emergency Calls**  
This phone, like any wireless phone, operates using radio signals, which cannot guarantee connection in all conditions. Therefore, you must never rely solely on any wireless phone for emergency communications.  
**Sound**  
This phone is capable of producing loud noises, which may damage your hearing. Turn down the volume before using headphones, Bluetooth stereo headsets or other audio devices.

**Phone Heating**  
Your phone may become warm during charging and during normal use.

### Electrical Safety

**Accessories**  
Use only approved accessories. Do not connect with incompatible products or accessories. Take care not to touch or allow metal objects, such as coins or keys, to contact or short-circuit in the battery terminals. Never puncture the surface of the battery with sharp objects.  
**Information on a Car**  
Seek professional advice when connecting a phone interface to the vehicle electrical system.  
**Faulty and Damaged Products**  
Do not attempt to disassemble the phone or its accessories. Only qualified personnel can service or repair the phone or its accessories. If your phone (or its accessories) has been submerged in water, punctured, or subjected to a severe fall, do not use it until you have taken it to be checked at an authorized service center.

### CTIA Requirements

**Do not** disassemble or crush, bend or deform, puncture, or shred.  
**Do not** modify or remanufacture, attempt to insert foreign objects into the battery, immerse or expose to water or other liquids, expose to fire, explosion or other hazard.  
**Only** use the battery for the system for which it is specified.  
**Only** use the battery with a charging system that has been qualified with the system per CTIA Certification Requirements for Battery System Compliance to IEEE 1725. Use of an unqualified battery or charger may present a risk of fire, explosion, leakage, or other hazard.  
**Do not** short-circuit a battery or allow metallic conductive objects to contact battery terminals.  
**Replace** the battery only with another battery that has been qualified with the system per this standard, IEEE Std-1725. Use of an unqualified battery may present a risk of fire, explosion, leakage or other hazard.  
**Promptly** dispose of used batteries in accordance with local regulations.  
**Battery** usage by children should be supervised.  
**Avoid** dropping the phone or battery. If the phone or battery is dropped, especially on a hard surface, and the user suspects damage, take it to a service center for inspection.  
**Improper** battery use may result in a fire, explosion, or other hazard.  
**The phone** shall only be connected to CTIA certified adapters, products that bear the USB-IF logo or products that have completed the USB-IF compliance program.

### Radio Frequency Interference

**General Statement on Interference**  
Care must be taken when using the phone in close proximity to personal medical devices, such as pacemakers and hearing aids.  
**Pacemakers**  
Pacemaker manufacturers recommend that a minimum separation of 15 cm be maintained between a mobile phone and a pacemaker to avoid potential interference with the pacemaker. To achieve this, use the phone on the opposite ear to your pacemaker and do not carry it in a breast pocket.

**Hearing Aids**  
People with hearing aids or other cochlear implants may experience interfering noises when using wireless devices or when one is nearby. The level of interference will depend on the type of hearing device and the distance from the interference source. Increasing the separation between the phone and the hearing device may also reduce the interference. You may also consult your hearing aid manufacturer to discuss alternatives.

**Medical Devices**  
Please consult your doctor and the device manufacturer to determine if operation of your phone may interfere with the operation of your medical device.

**Hospitals**  
Turn off your wireless device when requested to do so in hospitals, clinics or health care facilities. These requests are designed to prevent possible interference with sensitive medical equipment.

**Aircraft**  
Turn off your wireless device whenever you are instructed to do so by airport or airline staff. Consult the airline staff about the use of wireless devices onboard the aircraft. If your device offers a "flight mode," this must be enabled prior to boarding an aircraft.

**Interference in Cars**  
Please note that because of possible interference with electronic equipment, some vehicle manufacturers forbid the use of mobile phones in their vehicles unless a hands-free kit with an external antenna is included in the installation.

**Explosive Environments**  
**Gas Stations and Explosive Atmospheres**  
Avoid using your phone in areas with potentially explosive atmospheres, even if posted signs to turn off wireless devices such as your phone or other radio equipment. Areas with potentially explosive atmospheres include fueling areas, below decks on boats, fuel or chemical transfer or storage facilities, areas where the air contains chemicals or particles, such as grain, dust, or metal powders.

**Blasting Caps and Areas**  
Power off your mobile phone or wireless device when in a blasting area or in areas posted power off "two-way radios" or "electronic devices" to avoid interfering with blasting operations.

Copyright © 2016 ZTE CORPORATION. All rights reserved. No part of this publication may be quoted, reproduced, translated or used in any form or by any means, electronic or mechanical, including photocopying and microfilm, without the prior written permission of ZTE Corporation. ZTE Corporation reserves the right to make modifications on print errors or update specifications without prior notice. We offer self-service for our smart terminal device users. Please visit the ZTE official website at <http://www.zteusa.com> for more information on self-service and supported product models. Information on the website takes precedence. ZTE Corporation expressly disclaims any liability for faults and damages caused by unauthorized modifications of the software. Images and screenshots used in this guide may differ from the actual product. Content in this guide may differ from the actual product or software. This guide is published by ZTE Corporation.

ZTE, Citrine, and the ZTE logos are trademarks of ZTE Corporation. LTE is a trademark of ETSI. Google, Android and trademarks of Google, Inc. The Bluetooth® trademark and logos are owned by the Bluetooth SIG, Inc. and any use of such trademarks is under license by ZTE Corporation. The microSDHC logo is a trademark of SD-3C, LLC. Other trademarks and trade names are the property of their respective owners. Qualcomm and Snapdragon are trademarks of Qualcomm Incorporated, registered in the United States and other countries. Used with permission.

